


MS Manager





MS Manager

MS Manager can be a very useful tool when diagnosing problems with your system. The following slides give a briefly outline the features of MS Manager.







MS Manager

As seen in the figure below, MS Manager will display the part numbers of the modules connected within the mainframe.

Monitor	Slot		Module
	0		MS12-PM01-XX Loss Meter Status: Idle SN: 0001410353
	1		MS12-3050-XX-09FA Reflectance Meter 1310-1550 NM (...) Status: Idle SN: 5014050503





MS Manager

MS Manager also displays the serial numbers of the modules connected within the mainframe.

Monitor	Slot		Module
	0		MS12-PM01-XX Loss Meter Status: Idle SN: 0001410353
	1		MS12-3050-XX-09FA Reflectance Meter 1310-1550 NM (...) Status: Idle SN: 5014050503





MS Manager

A green box surrounding the module indicates that the module is ready.

Monitor	Slot		Module
	0		MS12-PM01-XX Loss Meter Status: Idle SN: 0001410353
	1		MS12-3050-XX-09FA Reflectance Meter 1310-1550 NM (...) Status: Idle SN: 5014050503


MS Manager

- A yellow box surrounding the module indicates that the module is busy.
- If you are not using the module at this time and the modules appears busy, please restart your system (PC and chassis). If problem persists contact JGR Optics.

Monitor	Slot		Module
	0		MS12-PM01-XX Loss Meter Status: Running SN: 0001410353
	1		MS12-3050-XX-09FA Reflectance Meter 1310-1550 NM (...) Status: Running SN: 5014050503

MS Manager

- When the module has trouble being read it will appear “Undefined” as shown in the figure.
- To solve this problem, turn off the mainframe and re-insert the modules.
- If problem persists contact JGR Optics.

<input type="checkbox"/>	3		Undefined Module Status: Undefined	SN: 0011350525
	4			

MS Manager

JGR's contact information is found under System Information within MS Manager.

